

MAYBERRY (ANDREW) POST

ANCHORING INSTRUCTIONS

1. Obtain proper anchor bolts, nuts, washers and template from manufacturer.
2. Pour a 36" concrete footer, making sure to adjust depth to your local frost level and allow for the inlet supply line. (footer should be a minimum of 3" larger in diameter than the provided template)
3. Place anchor bolts with threaded side up half way into the concrete.
4. Place the template over the anchor bolts with each anchor bolt aligning through the 4 holes of the template. Push anchor bolts into the concrete leaving approximately 2" of the threaded bolt above the concrete surface.
5. After situating to desired position, let concrete dry thoroughly. (Do not attempt the next step until the concrete has thoroughly hardened)
6. Place the post over the anchor bolts and secure using one washer and one nut per bolt.
7. For Gas: Slide the gas feed line down through the post with the coiled end at the top, remove the access door in the base to connect to your main supply line.
8. For Electric: Bring your main line in through your inlet supply and up through to the top of the post.
9. Follow the installation instructions packed with the lamp.

