

# BRENTWOOD POST

## ANCHOR INSTALLATION INSTRUCTIONS

1. Obtain proper anchor bolts, nuts, washers and template from manufacturer.
2. Pour a 36" concrete footer, making sure to adjust depth to your local frost level and leave access for the inlet supply. (footer should be a minimum of 3" larger in diameter than the provided template)
3. Place ½ of each anchor bolts with threaded side up into the concrete.
4. Place the template over the anchor bolts with each anchor bolt aligning through the 4 holes of the template.
5. Press the anchor bolts down into the concrete leaving approximately 2" of the threaded bolt above the concrete surface.
6. After situating to desired position, let concrete dry thoroughly. (Do not attempt the next step until the concrete has thoroughly hardened)
7. Remove the four nut covers from the base.
8. Place the base over the anchor bolts and secure using one washer and one nut per bolt.
9. Apply the nut covers.
10. Place the aluminum post in the base and tighten the (3) screws in the base to secure in place.(you may want to temporarily leave the plastic on the top part of the post.
11. Slide the top section of the decorative post down over the aluminum post and secure it to the base by tightening the (3) set screws at the bottom of the top section. Remove the plastic from the aluminum post and secure it by tightening the (3) set screws at the top of the top section.
12. For Gas: With the coiled end at the top, slide the gas feed line down through the post. Remove the plate from the bottom of the base(remove the (2) screws on each side of the plate) to access the connections then replace it when all connections are made.
13. For Electric: Feed the main line in through the inlet supply and up through to the top of the post.
14. Follow the installation instructions packed with the lamp.

